


TEKCAST 100D DOOR LATCH REPLACEMENT

Subject; Tekcast 100D Door Latch TZ01-127-R1

The original door latch was discontinued and up grade to a push button latch TZ01-127-93



DOOR HANDLE-RETRO-1-A7-10-301 HAS BEEN DISCONTINUED



#1 First punch a 1.250" HOLE in the cross beam 1.342 from the top.

#2 Then close the door and scribe a circle from the door hole.

#3 Install door catch if needed.